




# Breville®

## BES980




### Access the de-scale valve






*This document is the property of Breville Group which contains confidential and propriety information and is a reference document to be used only by the intended recipient and not shared with other parties. No part of the information may be used or reproduced in anyway without the written consent of Breville Group*

How to Access De-Scale valves		
Follow the below procedure to access the De-Scale valves		
1	<b>Remove the rubber cap as shown.</b>	
2	<b>Loosens 2 screws to release water / pressure in coffee &amp; steam boilers (Drip tray should stay in position).</b>	
3	<b>Set the dial wheel in lock position. Remove top cover (as marked).</b>	


*This document is the property of Breville Group which contains confidential and propriety information and is a reference document to be used only by the intended recipient and not shared with other parties. No part of the information may be used or reproduced in anyway without the written consent of Breville Group*

4	<b>Remove screw (as mark by yellow arrow)</b>	
5	<b>Pull out the top part, afterwards wheel can be remove from the bottom</b>	
6	<b>Remove the base cover by undo all screws and feet.</b>	

*This document is the property of Breville Group which contains confidential and propriety information and is a reference document to be used only by the intended recipient and not shared with other parties. No part of the information may be used or reproduced in anyway without the written consent of Breville Group*

7	<b>Remove both inner 4 screws (as mark by yellow arrows) to pull out inside cover</b>	
8	<b>Remove 2 screw as mark by yellow arrows to open the De-Scale valve cover.</b>	
9	<b>Pull out De-Scale valves</b>	

*This document is the property of Breville Group which contains confidential and propriety information and is a reference document to be used only by the intended recipient and not shared with other parties. No part of the information may be used or reproduced in anyway without the written consent of Breville Group*

10	<b>Remove the Cir Clip, and disconnect the valves (as mark by yellow arrows)</b>	
11	<b>Reassemble:</b> - Reverse the procedure from Step 10.	

*This document is the property of Breville Group which contains confidential and propriety information and is a reference document to be used only by the intended recipient and not shared with other parties. No part of the information may be used or reproduced in anyway without the written consent of Breville Group*